
## **TF1D QUICK START**

1 Connect power supply, motor and peripherals (See pages 4 and 5)




Three-phase power 400VAC + Neutral Three-phase Motor 400VAC in Star


2 Power the control panel, the screen will turn on



3 Enter the menu by pressing **BACK** and **ENTER** simultaneously




4 Select door type



**5** Select the maneuver mode (see page 7)



6 Test motor operation and adjust limit switches



**7** Perform the maneuver programming procedure. Make sure you have closed the door first.

Do not enter **OPTIONS** and **SETTINGS** menus, not necessary for programming



8 Test operation and tune OPTIONS and SETTINGS

Use **LL1**, **LL2** or a **transmitter** to test the operation of the maneuver. If necessary, modify the corresponding parameters in **OPTIONS** and **SETTINGS**.

